

Table of contents

Safety.....	2-3
General Introduction.....	4
Remote Control Unit.....	5-6
S.T.B Connection.....	7
Main Menu	8
1. Starting.....	8
1.1 Installation.....	8
1.2 Multi Satellite Scan.....	9
1.3 Satellite Edit.....	9
1.4 Transponder.....	9
1.5 Motor Configuration.....	10
1.6 USALS Setup.....	10
2. Channel Manager.....	11
2.1 Channel Edit.....	11
2.2 Favorite Manager.....	12
3. Preference.....	13
4. Setting.....	13
4.1Timer Setting.....	13
4.2 Child Lock.....	14
4.3 Date Time Setting.....	14
4.4 Upgrade.....	14
4.5 Version.....	14
4.6 Factory Reset.....	14

5. Display Setting.....	15
7.0 Media Center	16
7.1Media Center	16
7.1.1Record Manager	16
7.1.2Disk Manager	16
7.2Media Config	17
Warning.....	17
Trouble Shooting.....	18
Glossary.....	19
Specification.....	21

Safety Instructions

This STB has been manufactured to satisfy the international safety standards.
Please read the following safety precautions carefully.

MAIN SUPPLY:

INPUT: 100-240 v ~ 50/60Hz 0.6 A Max

OVERLOADING:

Do not overload a wall outlet, extension cord or adapter as this may result in fire or electric shock.
Ensure that the power source (socket) is easily accessible.

LIQUIDS:

This STB shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the STB.

CLEANING:

Disconnect the STB from the main supply before cleaning. Do not use any kind of solvents to clean the STB, only use a soft-dry cloth.

VENTILATION:

The slots on top of the STB must be left uncovered to allow proper airflow to the unit. Ensure a minimum distance of 5cm around the apparatus for sufficient ventilation. Ensure that the ventilation is not impeded by covering the ventilation openings with items such as newspapers, table-cloths, curtains, etc.

Do not stand the STB on soft furnishings or carpets.

Do not expose the STB to direct sunlight or do not place it near a heater.

Do not stack electronic equipments on top of the STB.

Do not place naked flame sources, such as lighted candles on the apparatus.

ATTACHMENTS:

Do not use any un-recommended attachments as these may cause hazard or damage to the STB.

CONNECTION TO THE SATELLITE DISH LNB:

Disconnect the STB from the main supply before connecting or disconnecting the cable from the satellite dish.

FAILURE TO DO SO CAN DAMAGE THE LNB.

CONNECTION TO THE TV:

Disconnect the STB from the main supply before connecting or disconnecting the cable from TV.

FAILURE TO DO SO CAN DAMAGE THE TV.

EARTHING:

The LNB cable MUST BE EARTHED to the system earth for the satellite dish.

LOCATION:

Place the STB indoor in order not to expose to lightening , rain or Sunlight.

Use the apparatus only in moderate climates (not in tropical climates).

Battery Handling:

Batteries may contain toxic agents that are hazardous to the environment. Therefore, dispose of the batteries immediately according to the prevailing statutory regulations. Never throw the batteries in normal household waste.

INTRODUCTION

This manual will help you learn basic functions such as installation, selecting channels and many other functions of the STB. All functions can be operated by the remote control. You can easily install it by selecting "**Installation**" function and upgrade its software through communication cable.

The remote control is designed for easy access to all the functions at once and for comfortable grab for your hand. It is programmed to control all functions and to easily watch TV and Radio programs via the STB.

WARNING

Any problems can be caused by the use of unofficial software. The use of software versions other than dealers or distributors official software will void the manufacturer's warranty. It is advised that only the formal software released from dealers or distributors should be used.

UNPACKING

Unpack the unit and check to make sure that all of the following items are included in the packaging.

1 x Remote Control Unit (RCU)

1 x User Manual

2 x AAA batteries

1 x Digital Satellite Receiver

1 x A/V Cable

1 x HDMI Cable

Remote Control Unit



1		Switches between Operation and Standby modes.
2	MUTE	Turns sound on or off.
3	ZOOM	Press to Zoom-in and Zoom-out picture.
4	SAT	To display SAT list.
5	PAUSE	Pauses to freeze the screen
6	TV/RD	Switch between TV and Radio mode.
7	BACKWARD	Press to make playing file backward
8	PLAY	Press to play the media files from USB disk
9	FORWARD	Press to speed playing
10	STOP	Press to stop file playing, and back to menu
11	FORMER	Press to skip the playing file to play the previous file
12	NEXT	Press to skip the playing file to play the next file
13	RECORD	Press to start recording TV program.
14	EPG	Press to Epg TV/Radio program guide broadcasting by Satellite TV provider.
16	MENU	Moves to main menu during TV viewing.
17	EXIT	Press to exit the current menu.
18	CH (▲)	Changes channels or items from top to bottom on the menu.
19	CH (▼)	Changes channels or items from top to bottom on the menu.
20	VOL (◀)	Changes down volume or items from top to bottom on the menu.
21	VOL (▶)	Changes up volume or items from top to bottom on the menu.
22	OK	Displays the channel list selects the item on the menu.
23	AUDIO	Shortcut to direct access Audio files from USB disk
24	INFO	Displays the program in formation box on the screen.
25	VOL (+)	Turns up volume
26	VOL (-)	Turns down volume
27	FAV	Selects favorite channel list or current ch list in the view mode. In Edit Channel mode's "Add favorite" menu it changes the right window's channel list.
28	RECALL	Press to jump to previous channel.
29	CH (+)	Turns up channel
30	CH (-)	Turns down channel
31	NUMBER KEYS	0-9
32	SUBTL	Subtitle functions
33	TXT	Displays TXT information broadcasting from satellite.

S.T.B Connection

Various equipment and TV/VCR can be connected to STB.
This manual will explain common ways to connect to the equipment.
If you experience any problem, please contact your sales agency.

1. How to connect the STB to a TV set

- (1) Connect HDMI cable to the HDMI socket on the back of the STB and the other end to the HDMI input socket on your TV.
- (2) Connect A/V RCA cable to A/V output on the STB, and the other end to A/V input socket on your TV.
- (3) Connect Scart cable to Scart output on the STB, and the other end to Scart input socket on your TV.
- (4) Connect the antenna cable to the LNB IN input connector of STB.



Main Menu

Plug in the STB. Then press the “**power**” button on the remote control or the “**Standby**” button on the STB Front Panel. The Main Menu screen, the beginning of the OSD screen, will appear as shown in the following picture. The Main Menu displays various functions of the STB or you can select with “**CH**” buttons and the numeric buttons on the remote control. To proceed to the next stage, press the “**OK**” button on the remote control.



1. Starting

Plug in the STB, and power on, Menu >> Preference >> OSD Language there are foreign languages for your choice, choose the one you prefer.

To get start the STB, please go to installation menu by pressing “**Menu**” button on the remote control (default lock code: 0000). The installation menu allows you to set the Antenna and various functions, and customize service. Use the “**CH**” buttons on the remote control to select an option and press the “**OK**” button to proceed to enter. To move backwards to the previous stage, press the “**Exit**” or “**Menu**” button.

1.1 Installation

Your STB can be easily installed by using “Installation” Menu.

Installation >> antenna Setting >> then Select your installed Satellite on the right side, and press “Vol+” button to enter into left side, then set all the other figures such as LNB type; Frequency; 22KHz; DiSEqC control; LNB Power and so on, using the “**Vol**” buttons on the remote control then press **Exit** button to **Save** the settings.



1.1 Installation

ALL / Network search : To Search out all the Free / Scrambled Channels available in particular Satellite or Transponders including the new transponders that are not preprogrammed in your STB but broadcasting by Satellite Provider. Then press the red button “Auto Scan” to start searching, while the related menu shows a details info of the scanning status.



1.2 Multi -Satellite Scan

Press red button “Auto Scan” to select the Satellite that you want to scan and your STB can be installed by up to 4 Satellites through a separated DiSEqC Switch component.

Press Green button “Manual Scan” to select one transponder which you want to scan.



1.3 Satellite Edit

In this menu, you can view the satellite information, and edit the satellite by Rename and Modify Using the “Vol” or numeric buttons.

Rename

To change the name of the Satellite

Modify

To modify the longitude and direction of the Satellite

Add

Press the red button to add the new Satellite to this STB.

Delete

Press the yellow button to delete the Satellite from this STB forever.



1.4 Transponder

You can edit with various option choices of transponder specifications and settings, also you can easily manually search only single transponder programs by selecting SCAN.



Add TP

Press Red button you can add a TP. Input the frequency value and symbol rate value by numeric key, choose the correct Polarization, Horizontal or Vertical, then save it.



TP Edit

Press Green button you can edit the current TP. Input the frequency value and symbol rate value by numeric key, choose the correct Polarization, Horizontal or Vertical, then save it.

Delete TP

Press Yellow button you can delete the current TP.

Scan

Press Blue button you can scan the current TP. The scan mode is the same as satellite, FTA; ALL; FTA+NIT; ALL+NIT.

1.5 Motor Configuration

To set up the auto Satellite Dish (DiSEqC1.2 system) and generate the positioner system.

Continuously Move

Motor setting >> USALS >> My Longitude then Using the "Vol" buttons to adjust West and East to move the dish, the bar of signal and quality at the bottom of the screen judge the best position of the dish.



Step Size

Adjust the Move Step from 1 to 10.

Move steps

Dish move step by step, adjust the dish to the best position.

Limit set

Using the "Vol" buttons to fix East or West limit or disable limit status.

1.6 USALS Setup

To set up the USALS system onto your STB.

If you have a USALS motorized system, you must set your position (latitude and longitude) in order to calculate all motor positions for viewable satellites. You should refer to the motor's manual to get.

Set the correct value of Longitude and Latitude of your position, press OK key, then you can see the moving direction and angle to your selected satellite from Motor menu.

Channel Manager

2. Channel Manager

You can easily access to any TV and Radio programs by the variable functions available from this STB, and enjoy your digital entertainment TV fun.

2.1. Channel Edit

Use the color buttons to select from Edit; Move; Skip; Delete functions to operate your TV programs.



Edit

Press Green button, then you can use the color buttons to Rename, Modify and Lock the channels.

Rename: Press Green button, you can change the name of selected channel.

Skip: Press **i+ Skip** button, you can skip the current channel. After that these channels can't show on the list.

Lock: Press Blue button to select the channel you wish to Lock, then press blue button, you can lock the selected channel from authorized watching.

Return: Press exit button, you can return to previous menu.

Move

Press Yellow button to select the channel you wish to move, then press Green button to pop-up Move-To menu and input channel numbers you wish to move, and press OK button again to insert.



Delete

Press red button to select the channel you wish to delete, then press blue button to delete the selected channel from STB.

Radio Channel Edit

Press the TV/RADIO button on remote control to change the TV mode to Radio mode, and then get into the "Channel Manager" menu, the same procedure as TV Channel Edit.



Channel List

Press OK button on the remote control, the channel list will be displayed, there are total 10 channels as well as brief information of channel in one page, and press "CH" buttons and "Vol" buttons to move in the list, and press "OK" button to select current channel, press "OK" button again, to exit Channel List Menu to enjoy watching.



With colored buttons (Red; Blue; Yellow; Green) presented at the bottom of menu, you can easily select the different sorting facilities, operating the related color buttons on remote control to select the desired functions.

SAT – stop button

Press Stop button to display ALL channels by original scanning order. If you search more than one satellite, also the satellite sorts the channels.

Find - Yellow

Press yellow button to display all of searched channels,

FAV Group – Press **Green** FAV button to highlights FAV group, and the channels are sorted by the FAV group.

2.2 Favorite Manager

The easy to use functions of Set Favorite enhance the flexibility of operating huge amount of TV and Radio Channels in your STB. Personalize it with your own way of interests can increase the joy of Digital Entertainment.



Set TV Favorite

There are total 8 groups of Favorite Sorting:

Example to make Channel 1 to News group -- FAV 1:

Move "CH" to Channel 1, then move "Vol" to select the group of FAV 1, press OK then you will see a logo displayed at the left beside channel 1, then press Red button to save, Now channel 1 is already within FAV 1 group.

Preference

3.Preference

This easy to use function for change of your language, audio and subtitle menus. You can easily set your OSD language and also preferred optional languages. Hard Hearing function for automatically show subtitle on supported channels.

Menu Languages

To select the preferred language by using “Vol” buttons.



Settings

4. Settings

With system menu, you can set whatever you want the features and specifications of your STB to be most suitable for your watching programs.


4.1 Timer Setting

There are total 10 Timers for you to arrange your program and in order not to miss your favorite program.

Using the “Vol” and “CH” buttons to select the preferred figures, and press “OK” button to set the different Timers, you can also set the preferred Power On channel in TV or Radio mode.

Timer Number

From 1 to 10, you can set total 10 different Timers



Timer Set

To open or close each Timer, if the Timer Set is off, then you can not continue to set Timer.

Timer Control: There are total 4 types of Timer type: Start time only; Stop time only; Both on.

4.2 Child Lock

To prevent the unauthorized Accessing of your STB, you can set the Parental control password to your receiver. (Default password: 0000)

System Lock: To lock the system menu to prevent unauthorized adjusting of system settings.

Parental Rating: You can define to verify authorization level between 0 to 18. You can also change the password by input numeric key for NEW Password, and then repeat again to VERIFY Password.



4.3 Date Time Setting

To set the local time and date to your STB, then save

Date Time Mode

Choose the format to display the Date Time.

Time Zone

Choose the time zone of your country belong to.

Summer Time

If you set summer time to "ON", then your local time should add one hour more.



4.4 Upgrade

Choose path to new software file, which is saved in USB device, select and press "OK" to proceed. It should be the first thing after updating to set factory default. 3 different update mode you should be use;

Usb/Card Upgrade :

You can update stb via usb or card.

FTP Client :

You can login to your FTP Server , to check Files, Photos ,etc..

Backup :

You can save your all Private Settings.



4.5 Version

Display this STB system information, such as software version, Hardware Info, Date and so on.

4.6 Factory Reset

To default the factory settings, by press master password after then it should be erased all channels and parameters , and press "OK" button to proceed.



Display

5. Display setting

To set the basic screen and output specifications of your STB. You can find the optional settings behind,

Contrast: To set contrast for best screen viewing

Brightness: To set brightness for best screen color

Saturation: To set darkness for best screen viewing

SPDF: To open or close digital audio output

Aspect Ratio: You can define your screen to the tv depends on video resolution

Video Output: To set your outputs ScartRGB, ScartCVBS, SVideo or Yuv

Video Resolution: To set your video outputs between 480i to 1080p

HDMI Color Space: To set your hdmi outputs for specific television with regular settings

HDMI Deep Color: To set your hdmi outputs for specific cables to connect to television

HDMI Audio: to set your HDMI Audio , HDMI_Mute – HDMI_Raw – HDMI- PCM



Media Center

7. Media Center

Media Center menu on the device with internet connection has gained a lot of functions. This is strictly an internet connection is needed to operate the functions. This one also adds value to the device functions. If you want to upgrade your stb, you can use ftp functions to download latest firmware.



7.1 Media Center

This sub menu includes most important functions with internet connections. You can get a connection direct weather forecast or you can download movie and games for enjoy. You can check the position of somewhere with google map functions. These are only for beginning add-ons and also you can add more functions at the feature.

7.1.1 Record Manager

Record favorite TV program to USB device, and review it at anytime in future.

Partition Select

Only root directory is available, can't set path to folders.

Information

Press "Info" button to check details information when recording, such as recorded time, available free memory size etc.

Format of recorded file

Recorded file will be saved in format of MPG or TS.

7.1.2 Disk Manager

You can change the all parameters of the usb device from disk manager menu. Change your disk types or modify details of the files.

Move/copy

Copy or move of your contents to an other location.

Rename

Rename of your contents and files.

Delete/Delete All

Delete separate files one by one or delete all files in the folder



7.2 Multi Media Config

On this menu you can configure the specific future. Only changes must be done with this menu functions.

Subtitle language

You can choose true subtitle language for Movie, Music, Picture, EBook..

Subtitle Code Page

You can change system subtitle codes for Movie, Music, Picture, EBook



Repeats

You can choose 3 different repeat functions; On/Off/Folder continuously repeat

BGmusic

You can start and stop back ground music function when the slide show begins.

Slide Time

You can configure slide time changes between 3-15 seconds.

Efect

You can choose more screen showing types for slide show

File Size

You can select each block length for your records.

Warning

WARNING

USB1.1 or USB2.0 Key or Stick (Including MP3 player)

We strongly suggest not to record any TV program by USB Key or Stick, because a huge of different USB Key or Stick are indeed available in the market with different quality level, we do not guarantee any damage of your USB Key or Stick from the attempting recording.

Do not remove your USB device from STB while it is in use of any USB multimedia function.

Supported Device:

Most of popular USB2.0 Hard Drive Disk can be supported by our STB, however due to there are too many types of HDD available in the market, if you find one particular HDD can not work with our STB, please kindly provide it to us, and we will be happy to solve

it for you in shortest time.

System required: FAT, FAT32, NTFS

Speed required: 5400rpm, 7200rpm

Instructions to TV program

Any SD TV program (Standard Definition) with a bit rate lower than 6Mbps can be recorded by this STB.

During recording, EPG; TXT; Multi AUDIO functions can not be operated.

Recorded TV program will not support EPG; TXT; Multi AUDIO.

Recording Capacity

Our STB can support up to 4 partition of one HDD, and theoretically each partition can allow up to 2TByte (2,000Gb), however, we suggest to use one HDD with each partition not bigger than 120Gb

Each recorded video file will not bigger than 3.8Gb (Approx 4 hours), the STB will automatically create new video file to continue recording your TV program if the recorded video file is bigger than 3.8Gb.

How to choose and set different partition from my HDD ?

Then the recorded video file will be stored into this partition.

Trouble Guide

Fault Phenomenon	Probably reasons	Resolve
Power on, but no display on screen	Please carefully check the power plug, to see it is in socket of wall or not? Is power interrupted?	Put firmly the power plug to the socket on the wall.
Power on this STB then that screen Displays "No signal"	Is the aerial install correct?	Reinstall the aerial and calibrate it
	LNB input is not connect	Connect the LNB
	The transmit station turns off	Attempt until the signal coming again
	The sky wave disturbs the device	Attempt again later
	The program setups are incorrect	Set the proper parameters of received program in the system settings menu

STB plays a strange sound	Due to the channel contain more audio tracks or audio languages	User can use the "Audio" button on the RCU to select the correct audio track or audio languages
USB Game Become Black and White	The TV color system setting is not same as STB TV type	Make sure the STB TV system set to the same system (PAL; NTSC; AUTO) of TV system.

Tips: If you refer to this troubleshooting, but no resolve that problem you encountered. Please contact the local dealer or technical support instantly, do not open the machine, because that is very dangerous to you or to the machine in that cases.

Glossary

(1) 22KHz switch

A tone that can be sent via the LNB coax, this tone can control the LNB or switches on the coax cable. Do not interfere with the DC or 22KHz tone that the receiver sends to the dish.

(2) Antenna

A device that collects and radiates electromagnetic waves includes a satellite dish and a broadband antenna.

(3) CVBS

Composite Video Baseband Signal, Standard single-wire video, mixing luma and chroma signals together.

(4) DiSEqC

Digital Satellite Equipment Control, a protocol established by EUTELSAT organization www.eutelsat.com, the most popular standard are DiSEqC 1.0 for Switching solution, DiSEqC 1.2 for Dish actuator solution, and DiSEqC 2.0 for Satellite Receiver solution.

(5) Forward Error Correction (FEC)

A system of error control for data transmission

(6) Frequency

The number of cycles or events per one second, which is expressed in the unit of Hertz(Hz)

(7) Intermediate Frequency (IF)

A frequency to which a carrier frequency is shifted as an intermediate step in transmission or reception

(8)Low Noise Block (LNB) Downconverter

A low noise microwave amplifier and converter which downconverts a range of frequencies to IF range

(9)NTSC

National Television Standards Committee, a video standard established by the United States (RCA/NBC) and adopted by numerous other countries.

(10)PAL

Phase Alternate Line, a video standard used in Europe and other parts of the world for composite color encoding.

(11)Packet Identifier (PID)

A set of numbers that identifies transport stream packets containing data from a single data stream

(12)Polarization

Satellite waves are polarized. They can be linear or circular. Linear polarity is Vertical or Horizontal, circular polarity is Right-hand and Left-hand circular polarity.

(13)Quaternary Phase Shift Keying (QPSK)

Phase-shift keying in which four different phase angles are used.

(14)RF

A frequency that is useful for radio transmission, usually between 10KHz and 300,000Mhz.

(15)RGB

Video information in the form of Red, Green and Blue tristimulus values, The combination of three values that representing the intensity of each of the three colors can represent the entire range of visible light.

(16)STB

Set Top Box, another common name of Digital Satellite Receiver, because it usually be put on top of TV in household. This word is used now worldwide.

(17)Symbol Rate

The amount of data transmitted every second.

(18)Transponder (TP)

Equipment in a satellite which receives a single uplink channel from a satellite earth station, amplifies it, converts the frequency and changes the polarization, then broadcasts it back to earth.

(19)Transport Stream

The bit stream formed prior to transmission of signals by combining the video, audio and data streams of one service. It consists of fixed length packets of 188 bytes of data.

Specification

1. Tuner & Demodulator

Input Frequency Range	950MHz-2150MHz
Input Signal Level	-64 dBm ~ -25 dBm
Impedance	75 Ω
Bandwith	55 MHz/8 MHz (Under 5 Msps)
LNB Power	13/18 DC, +/-5%, 0.5A max
LNB Tone Switch	22 KHz +/- 2KHz, 0.64V p-p +/-0.15V
DisEqC Control	V1.0, V1.2, Tone burst A/B
Demodulation	QPSK
Symbol Rate	1 ~ 45 Msps/SCPC, MCPC

2. MPEG

Transport Stream	MPEG-4, H.264, MPEG-2 ISO/IEC 13818 Transport Stream Specifications
Input Rate	Max. 120 Mbit/s
Video	MPEG-2 MP@ML- MPEG-1/2/4
Audio	MPEG-1/2 Audio Layer1 or Layer2, MPEG2 MPEG4 AAC and MPEG4 AAC-HE(AAC+), Dolby Digital (AC-3), MP3, WMA
Aspect Ratio	4:3 LB,4:3PS,16:9, Full screen
Video Resolution	Auto Detect,480i,480p,576i, 576p, 720p,1080i,1080p
Audio Mode	Stereo, Dual Channel, Joint Stereo, Mono ,AC3
Audio Sampling Frequency	32,44.1/48KHz

3. Connector

LNB IF input	F type, IEC 169-24 Female
HDMI	HD Video/Audio, Ver 1.2, Type A
RCA	AUDIO L/R, CVBS, 0/12V

4.Power Supply

Input Voltage	100-240 v ~ 50/60Hz 0.6 A
Power Consumption	Max 25W
Standby Power	Max 1W
Weight	Appr. 100 GR
Operating Temperature	0°-40°
Storage Temperature	-40° - 60°

5.Main System

CPU	667 MHz
Flash (NAND FLASH)	8 MByte (64 Mbit)
S-Dram (DDR I)	2G (128 Mbit)
USB	USB 2.0